



INVENTED BY

Robert Sweeney
+3477 INFLUENCERS

Tripper was invented by Robert Sweeney, an industrial designer from Winnipeg, Manitoba.

When Robert was a kid, he snuck into his mom's closet and managed to consume a couple of mothballs, landing himself in the ER.

He vowed to invent an easy-to-use sensor that parents could use to monitor living spaces. Hopefully Tripper will help prevent household accidents like his!

TRIPPER

SMART WINDOW/DOOR SENSORS

- Allows door and window activity to be monitored via your mobile device
- A magnet is used to detect when the two pieces of the device are separated or joined
- Tripper can notify you via the app when door or window status changes
- Easy to install and use



IN THE BOX

- 2 Tripper window/door sensors with adhesive, each with 2 parts: a sensor and a magnet
- Pre-installed CR2032 batteries; one per sensor
- User guide

WHAT YOU'LL NEED

- A Wink HUB or ZigBee-enabled Wink-certified hub (sold separately)
- Apple® or Android™ smart device (tablets and desktops not supported)
- The Wink app downloaded to your mobile device from the iTunes® App Store or Google Play™. If you already have the Wink app installed, please download the latest version to ensure you have the most updated support.
- Wi-Fi® network

IMPORTANT SAFETY INFORMATION

- Read all instructions and warnings prior to using Tripper. Failure to comply with instructions and warnings constitutes improper use of Tripper. Save all instructions.
- Quirky, Inc. is not responsible for improper use, which may result in personal injury or product damage.
- Not a toy. Keep away from children.
- There are no user-serviceable parts.
- DO NOT USE AS A HOME SECURITY DEVICE. Tripper should only be used to monitor window and door status and does not guarantee home security. Use a properly installed and maintained alarm system to reduce your risk of a burglary, robbery or other events.

COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

LIMITED ONE-YEAR WARRANTY

Quirky, Inc. ("Quirky") Original Purchase Product Warranty:

Quirky warrants to the original purchaser ("Purchaser") of this Quirky product, for the period of one (1) year following the date on which Purchaser purchases the product, that the product shall be free of defects in design, assembly, material, or workmanship.

Quirky will refund or replace, at its option, any defective product free of charge.

In order to qualify for this warranty, the Purchaser must provide the defective product and a copy of the original receipt of purchase to Quirky for inspection. The receipt of purchase must indicate the product purchased, price paid, date of purchase, and name of merchant.

To request service under this warranty, contact Quirky at 866-5-QUIRKY or questions@quirky.com and a Quirky representative will provide instruction on how to proceed.

This warranty shall be null and void if Quirky determines that the product has been improperly installed, altered or tampered with in any way. This warranty does not protect against normal use, wear and tear, or damage due to abuse.

THIS WARRANTY CONTAINS THE SOLE WARRANTY OF QUIRKY. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE IMPLIED WARRANTY OR CONDITION OF QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND SUCH IMPLIED WARRANTIES, IF ANY, ARE LIMITED IN DURATION TO THE TERM OF THIS WARRANTY. IN NO EVENT SHALL QUIRKY BE LIABLE FOR INCIDENTAL, SPECIAL, DIRECT, INDIRECT OR CONSEQUENTIAL DAMAGES SUCH AS, BUT NOT LIMITED TO, LOST BUSINESS OR PROFITS ARISING OUT OF THE SALE OR USE OF ANY QUIRKY PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some jurisdictions do not allow exclusions or limitations on implied warranties or incidental, consequential or other damages, so the above exclusions and limitations may not apply to you.

COPYRIGHT AND TRADEMARK NOTICES

© 2015 Quirky, Inc. All rights reserved.

Quirky is a registered trademark of Quirky, Inc.

GE is a registered trademark of General Electric Company and is under license by Quirky, Inc.

Wink is a trademark of Wink, Inc.

Wi-Fi is a registered trademark of the Wi-Fi Alliance.

ZigBee is a registered trademark of ZigBee Alliance.

Apple and iTunes are registered trademarks of Apple, Inc.

App Store is a service mark of Apple, Inc.

Android and Google Play are trademarks of Google, Inc.

SUPPORT

Need help?

Email questions@quirky.com
Call 1-866-5QUIRKY


R-INS-TRPR-WH02 | rev020615






INSTALLATION INSTRUCTIONS

- 1 Ensure window or door is closed.
- 2 Place one part of the sensor on the stationary portion of the window or door (e.g., the frame) using adhesive. Surface must be clean to ensure a good bond.
- 3 Place other part of the sensor on the moving portion of the window or door, using adhesive. The sensor parts should be within 1/8" of each other when closed. Make sure there is clearance during movement, so it does not get pushed off.




CONNECTING TRIPPER TO THE WINK APP



Open the Wink app on your mobile device and log in with your email address and password. If this is your first time using the Wink app, tap "Sign Up" to create an account.



Remove the plastic tab that is sticking out from the battery portion of the sensor. This will activate the pairing mode. The LED light will flash green during pairing.



Follow the steps provided on the Wink app. When the Wink app displays "Success," Tripper is connected. If the pairing mode ends before connecting Tripper to the Wink app, you can restart the pairing mode by simply opening and closing the door or window.



To reset or pair Tripper to a different Wink account or hub, open from the indent on the side of the main sensor. Press and hold the black tamper button while taking out the battery. Put the battery back in and let go of the tamper button.